

Casio Watches App Guide

G-SHOCK EXAMPLE MODEL - MRGB5000

G-SHOCK



Index

CASIO Watches (Smartphone App)3
G-SHOCK Connected Models
G-SHOCK Example Model
Initial Setup
Region Selection / Software Usage / Privacy Notice6
CASIO ID Login / Homepage7
Initial Watch Registration & Connection8-9
My Watch - Watch Features

Home / My Watch / My Page10
Accessing the Watch Setting from the Home Tab11
Finding the Watches Settings and Features on the App12
Alarm13
Timer14
Reminder15
World Time16-17
Home Time & Daylight Savings Time18
Watch Self-Check Status & History19
Premium Production Line Certificate20
Phone Finder21

My Watch - Watch Settings

Key Sounds	22
Watch Light Settings	23
Watch Display Settings	24
Power Saving Function	25
Change Time Display	26
Watch Connection Time with the App Settings	

My Watch - Tutorial

Connection with the Watch Pop-up Message	28
About the TIME & PLACE Feature	29
Mobile Link Help Web Page	30

Pop-up Watch Menu

Delete Watch Info from App	31
Remove Pairing Info from App	.32
Edit Watch Info on the App	.33

CASIO Watches App Menu

Q&A Web Page34	ł
Mobile Link Help Web Page35	;
Edit User Profile	,
Change Display Unit Settings	,
CASIO ID Account Web Page	}
About This App)

CASIO Watches (Smartphone App)



CASIO WATCHES SMARTPHONE APP





Confirmed OS versions 🗍

MRGB5000 App Features

Watch Status Display

Graphical display of time-reception status, solar power generation status, internal data update history and more.

Self Check

Automatic evaluation of watch functions' operational status. Displays a screen alert in the case of malfunction.

Time & Place Log

Pressing a button on the watch records the current date/time and position on a map within the app. Useful as an activity log.

Reminder Setting

The watch will remind you of up to five upcoming events, which you set within the app.

Local Calendar

Supports days of the week, languages, and month/day display orders for U.K., Spain, Germany, France, Italy, and Russia.

Automatic Time Adjustment (four times a day)

- World time for over 300 cities
- Home time/ world time switching
- Countdown timer/ alarm setting
- Phone finder



FROM THE MR-G SERIES, THE PINNACLE OF THE G-SHOCK LINEUP, COMES A NEW DESIGN BASED ON THE ORIGINAL DW5000C. The trademark square shape is elevated by utilizing special, premium metal materials and artisan craftsmanship that the MR-G series represents.





\$3,500

All Models

Shock Resistant 200-Meter Water Resistance Tough Solar (Solar powered) Bluetooth® Connected Brick Pattern Frame Around Digital Display Cobalt Alloy COBARION® Bezel Individually Polished Parts with Sallaz Polishing LED Backlight (Super illuminator) Power Saving Feature 5 Daily Alarms







MIRROR FINISH

The MRGB5000B-1 model enhances the mirror finish of the COBARION® material by adding a glossy finish with black DLC (diamond-like carbon), which is meant to resemble the original black DW5000C.



DIAL DESIGN

A brick pattern and a red line for the frame around the digital display adorn the screen, which are identifying characteristics of the original DW5000C.



EXTERIOR DESIGN

A new shock-resistant multi-guard structure increases strength by using stainless steel leaf springs and silicon between bezel parts.



TITANIUM ALLOY

The case and bezel are made of high-hardness Ti64 titanium alloy, and the band is made of DAT55G titanium alloy, which is approximately three times harder than pure titanium and provides excellent workability.



ELEGANT BEZEL

The new MRGB5000 model features an intricately shaped bezel made up of 25 parts that have been individually polished with Sallaz polishing, which gives the watch a stunning, elegant finish.



NEW MODULE

Function-wise, the MRGB5000 also features a special-purpose MR-G module with gold-plated circuit retainer plates to reduce electrical resistance and is also equipped with time signal reception and Bluetooth® communication capabilities for smartphone connectivity.



FUNCTIONAL POWERHOUSE

These metallic beauties deliver when it comes to function too, with radio-controlled calibration, full auto LED (super illuminator) backlight, and smartphone pairing via Bluetooth®. REGION SELECTION / SOFTWARE USAGE / PRIVACY NOTICE



After downloading the Casio Watches App from the app store or google play store start by opening the app and select GET STARTED to begin the initial setup. Select the desired region by selecting CHANGE REGION SELECTION then select CONFIRM SETTINGS AND PROCEED.

After reviewing the Software Usage Agreement information select AGREE AND PROCEED.

After reviewing the Privacy Notice information select AGREE AND PROCEED.

Initial Setup CASIO ID LOGIN / HOMEPAGE



Casio watches app will now be accessible.

information on why to create a CASIO ID to get more information on why to create a CASIO ID account. To create or login with a CASIO ID select LOG IN WITH CASIO ID to continue as a guest select LOG IN AS A GUEST.

CASIO Watches App Guide

Initial Setup

INITIAL WATCH REGISTRATION & CONNECTION



Initial Setup

INITIAL WATCH REGISTRATION & CONNECTION



HOME / MY WATCH / MY PAGE



Home Tab

On the home tab will allow the option to access your watch on the top left corner or scroll down to see the G-Shock Instagram feed.

My Page Tab

My watch tab will show you all of the watches that have been connected and registered through this application and will also allow you to connect a new watch through the use of the plus in the bottom right corner.

The my page tab will show the purchase history of the watches that have been registered to the application and Casio ID account.

ACCESSING THE WATCH SETTING FROM THE HOME TAB



Step 1

To access the watch from the home screen select the icon in the top left corner of your watch.

Step 2 A prompt will appear that will give the option to view the instruction manual for this model or access to my watch portion of the application to access setting features.

Instruction Guide

Upon selecting the instruction the application will redirect to the Casio website displaying the instruction operation guide.

To My Watch

Upon selecting to my watch the watch setting and features page will appear.

FINDING THE WATCH SETTINGS AND FEATURES ON THE APP



Step 1

Step 2

To access the watch settings and features for a specific watch from your my watch tab select the watch you would like to adjust from the list above.

Scroll down to see the watches' feature and settings.

Step 3

Select the setting you would like to adjust from the list above.

ALARM



Step 1

Step 2

To access the alarm feature and settings find the my watch tab then select the desired watch from the list above.

Scroll down from this watch is homepage.

Step 3

Then select alarms from the list above.

Step 4

Select the desired alarm setting that needs to be updated to change the time of the alarm then select the toggle to the right of the time display and select sent settings to watch to complete the process.

TIMER



Step 2

To access the timer feature and settings find the my watch tab then select the desired watch from the list above.

Scroll down from this watch is homepage.

Then select timer from the list above.

Set the desired time for your countdown timer and then select send setting to watch to complete the process.

REMINDER



To access the reminder feature and settings find the my watch tab then select the desired watch from the list above.

Scroll down from this watch is homepage.

Select the desired reminder setting that needs to be updated enter the reminder description information and select the toggle next to the name of the reminder when finished then select send settings to watch to complete the process.

Then select reminder from the list above.

WORLD TIME



To access the world time feature and settings find the my watch tab then select the desired watch from the list above.

Scroll down from this watch is homepage.

Select the world time that needs to be updated from the list above to begin the process.

Then select world time from the list above.

WORLD TIME CONT.



(Continued from previous page) .

Step 2

Either introduced city in the search bar at the top of the app as displayed above or select from the list of cities shown for the desired Time zone.

Select send settings to watch to complete the process.

HOME TIME AND DAYLIGHT SAVINGS TIME



To access the world time feature and settings find the my watch tab then select the desired watch from the list above.

Scroll down from this watch is homepage.

The home time should automatically be adjusted when connected to the smart phone but to edit select the time zone above enter the desired Location then select sunsetting to watch to complete.

Then select world time from the list above.

WATCH SELF-CHECK STATUS AND HISTORY



To access the watch status feature and settings find the my watch tab then select the desired watch from the list above.

Scroll down from this watch is homepage.

Select execute self check to begin the watch self check process to see the wax self check history select status check history this will give you a list of all of the watches self checks.

PREMIUM PRODUCTION LINE CERTIFICATE



To access the premium production line certificate find the my watch tab then select the desired watch from the list above.

Scroll down from this watch is homepage.

Here will be displayed the premium production line certificate of this watch from the Yamagata factory in Japan.

the list above.

PHONE FINDER



To access the phone finder feature and settings find the my watch tab then select the desired watch from the list above. Scroll down from this watch is homepage.

Select the desired phone finder settings from above then select safe to complete the process.

Then select phone finder from the list above.

KEY SOUNDS



To access the key sounds feature and settings find the my watch tab then select the desired watch from the list above.

Scroll down from this watch is homepage.

Use the toggle to turn the key sound on or off when the black bar is displayed the key sounds are turned on then select in settings to watch to complete.

Then select the watch settings drop-down menu from

this menu select key sounds.

WATCH LIGHT SETTINGS



To access the light feature and settings find the my watch tab then select the desired watch from the list above.

Scroll down from this watch is homepage.

Then select the watch settings drop-down menu from this menu select light.

Page 23 of 39

Use the toggle to activate or deactivate the auto light

feature on this watch select the desired length of time

for which the length of time the light will switch on for then select send settings to watch to complete the

process.

WATCH DISPLAY SETTINGS



To access the Watch display feature and settings find the my watch tab then select the desired watch from the list above.

Scroll down from this watch is homepage.

Select the desired watch display settings from the above list then select send settings to watch to complete the process.

this menu select Watch display.

POWER SAVING FUNCTION



To access the Power saving feature and settings find the my watch tab then select the desired watch from the list above.

Scroll down from this watch is homepage.

Then select the watch settings drop-down menu from this menu select Power saving.

Use the toggle displayed above to activate or deactivate the power saving feature then select send settings to watch to complete the process.

CHANGE TIME DISPLAY (SWAP HOME AND WORLD TIME)



To access the change time display feature and settings find the my watch tab then select the desired watch from the list above.

Scroll down from this watch is homepage.

Use the selections above to switch your home time in world time settings on your watch when completed select send settings to watch to complete the process.

Then select the watch settings drop-down menu from

this menu select change time display.

WATCH CONNECTION TIME WITH THE APP SETTINGS



To access the connection time with the app feature and settings find the my watch tab then select the desired watch from the list above.

Scroll down from this watch is homepage.

Then select the watch settings drop-down menu from this menu select connection time with the app.

Select the desired connection time with the app from

the selection above, when completed select send

settings to watch to complete.

My Watch – Tutorial

CONNECTION WITH THE WATCH POP-UP MESSAGE



To access the initial connection with the watch pop-up message find the my watch tab then select the desired watch from the list above.

Scroll down from this watch is homepage.

Then select the tutorial drop-down menu from this menu select connection with the watch.

Here will be displayed the initial connection with the watch pop up message, after reviewing select close to complete.

My Watch – Tutorial

ABOUT THE TIME & PLACE FEATURE



To access the about time and place description, find the my watch tab then select the desired watch from the list above. Scroll down from this watch is homepage.

Then select the tutorial drop-down menu from this menu select about time and place.

Page 29 of 39

Here will be displayed the about time and place

description information.

My Watch – Tutorial

MOBILE LINK HELP WEB PAGE



To access the mobile link help web page, find the my watch tab then select the desired watch from the list above.

Scroll down from this watch is homepage.

Then select the tutorial drop-down menu from this menu Here you will be directed to the support.casio.com webpage on mobile link help.

select Mobile link help.

Pop-Up Watch Menu

DELETE WATCH INFO FROM APP



Step 3

Select delete watch info and confirm to complete the process.

To delete watch info from the application, find the my watch tab then select the desired watch from the list above.

Select the pop-up menu by selecting the three dot menu option displayed above.

Pop-Up Watch Menu

REMOVE PAIRING INFO FROM APP



Step 1

To remove watch pairing from the application, find the my watch tab then select the desired watch from the list above.

Select the pop-up menu by selecting the three dot menu option displayed above.

Step 3

Select remove pairing to complete the process.

Pop-Up Watch Menu

EDIT WATCH INFO ON THE APP



To edit watch info on the application, find the my watch tab then select the desired watch from the list above.

Select the pop-up menu by selecting the three dot menu option displayed above.

Select edit watch info and confirm to complete the process.

Here will be displayed the edit watch info after making

the desired changes select apply to complete the

process.

Q&A WEB PAGE



	CASIO WORLDWIDE
>	\clubsuit $>$ $>$ $>$ $>$ Smartphone Link (G-SHOCK Connecte
>	Smartphone Link (G-SHOCK Connected etc)
>	Smartphone Link (G-SHOCK Connected etc)
>	Smartphone Link (G-SHOCK Connected etc)
>	Most Read FAQ Recently Updated FAQ Q1. Auto time adjustment is not performed. Q2. The App crashes and fails on Android OS.
	Q3. Cannot connect via Bluetooth. The app stopped working properly.

Step 3

Here you will be redirected to the support.casio.com webpage displaying the Q&A a information.

right corner of either the home tab, the my watch tab, or

the my page tab to get the drop down menu.

MOBILE LINK HELP WEB PAGE



tab, or the my page tab to get the drop down menu.

EDIT USER PROFILE



 Kenu
 Kenu

 Q&A
 Pr

 Mobile Link Help
 Pr

 App Settings
 Bi

 User Profile
 Pr

 Display Unit Settings
 Pr

 Account
 Pr

 About This App
 Pr

ul 🕆 🕞

1:14 🕇	ull 🕈 💽
<	User Profile
Profile	
Display Name	
John Doe	
Birth Date	Nov 24, 1990 >
Sex	Male >
Profile Icon	



Step 1

To access the user profile settings for this app find the application settings menu by selecting the three bars in the top right corner of either the home tab, the my watch tab, or the my page tab to get the drop down menu.



1:13 4

Select user profile.



Step 3

Enter or select the desired changes to the user profile then select save to complete the process.

CHANGE DISPLAY UNIT SETTNGS





ull 🕆 🗊



Different data types will use different units.



Step 1

To access the display unit settings for this app find the application settings menu by selecting the three bars in the top right corner of either the home tab, the my watch tab, or the my page tab to get the drop down menu.



1:13 4

Select display unit settings.

Step 3

Select the display unit settings to be displayed on the watch and the application, select save to complete the process.

Save

CASIO ID ACCOUNT WEB PAGE





Step 1

To access the CASIO ID account info for this app find the application settings menu by selecting the three bars in the top right corner of either the home tab, the my watch tab, or the my page tab to get the drop down menu.

Step 2

Select Account.

Step 3

Select my page to be redirected to your CASIO ID information page or select log out to log out of your CASIO ID account on this application.

ABOUT THIS APP

3:01 7

0

G-SHOCK



CASIO_®



Step 1

To access the about this app information for this app find the application settings menu by selecting the three bars in the top right corner of either the home tab, the my watch tab, or the my page tab to get the drop down menu.

Step 2

Select about this app.

Step 3

Here you will find the current version of this app, the time zone Dana, the software usage agreement, the privacy notice, and the software license for this app.